

TEM TECHNICAL BULLETIN #5:

TAS Socket— Fitting to TEM NM25 – NM32 Frame

The NM25 & NM32 Frame require a Rear Mounted adaptor.

The frame comes pre-assembled and only requires insertion of the socket.

Connect the wires prior to press fitting the socket into the frame.

The orientation of the frame with the position of the Socket is important. Large Ridge is to the Top of the Socket.

Dis-assembly: - Access to Socket Connections

Removal of the socket from the frame is best achieved by removal of the frame from the box.

Removal of the adaptor is not possible.

