

TEM TECHNICAL BULLETIN #6:

TAS Socket— Fitting to TEM N40M – NM70 Frame

The NM40 & NM70/72 Frame: No adaptor required.

The socket comes pre-assembled and only requires insertion of the socket into the frame.

Connect the wires prior to press fitting the socket into the frame.

Vertical or Horizontal orientation of the frame with the position of the Socket is possible.

Check carefully before final fitting as removal is not possible after press fitting the Socket.

Dis-assembly: - Access to Socket Connections

Removal of the socket from the frame is best achieved by removal of the frame from the box.

Removal of the adaptor is not possible.

